



The electrical equipment contained in this box should not be disposed of in unsorted municipal waste but collected separately. This is intended to reduce the impact on the environment by minimising the level of waste generated at the end of a product's useful life by increasing the percentage of material recovered and recycled.

UCF100TRS Extract Fan – Trickle Speed with Pullcord Boost



Installation and Operation Instructions

Regency House
Kingsclere Park
Kingsclere
Newbury
Berkshire RG20 4SW

Tel: 01635 299266

www.ferrob.co.uk

FERROB
ENVIRONMENTAL SYSTEMS

INSTALLATION

THROUGH A WALL

1. It is recommended that the unit is installed not less than 1.75m from the floor and is not installed directly above a heat source. i.e. radiator etc.
2. Cut a 107mm diameter hole in the wall ensuring that the hole slopes slightly to the outside to prevent any water from running back into the sleeve.
3. Fit the plastic wall sleeve and drill, plug and screw the body of the fan into position ensuring that the sleeve is fitted over the fan spigot.
4. Place the external grille into position and then drill, plug and screw into place.

THROUGH A CEILING

1. Cut a 107mm hole in the ceiling ensuring that the hole is central between joists.
2. Using suitable fasteners, fix the fan body into position over the hole.
3. Affix the ducting to the fan spigot.
4. Connect the other end of the ducting as required to a suitable outlet. (soffit grille etc)

Ferrob Ltd also recommends the fitting of a condensation trap when connected to a vertical run of ducting.

ELECTRICAL CONNECTION

All wiring must comply with the latest edition of the IEE wiring regulations. If in any doubt, contact a registered or approved electrician.

A means for disconnection from the supply having a contact separation of at least 3mm in all poles must be incorporated into the fixed wiring.

The unit is rated at a maximum power consumption of 20watts.

OPERATION

THE UCF 100 TRS EXTRACTOR FAN RUNS CONTINUOUSLY AT TRICKLE SPEED WITH A PULLCORD OPERATED MANUAL BOOST OVER-RIDE.

1. When the power supply to the unit is switched on it will begin to run immediately.
2. The fan will run continuously on trickle speed.
3. When extra ventilation is required, gently pulling on the pullcord will cause the unit to run on boost speed. Another pull on the cord will revert the fan to running on slow speed.

If a remote boost switch is required, disable the existing pullswitch inside the fan and connect 2 wires from the terminal block located on the printed circuit below the pullswitch. Run these 2 wires to a remote switch.

These are 230v connections

